

SW No.	Function	ON	OFF	shipment
1-1	Data reception errors	Ignores	Displays"?"	OFF
1-2	Data length	7bits	8bits	OFF
1-3	Parity	Parity	Without parity	OFF
1-4	Parity selection	Even parity	Odd parity	OFF
1-5	Change baud rate	(Refer to Table 4.2)		ON
1-6				OFF
1-7	Self-test selection*	Perform self-test	Do not perform	OFF
1-8	Communication mode	Mode B	Mode A	OFF

* The DM-D101II performs a display test once at power-on.